



# BEACON POWER MANAGEMENT SYSTEM INSTALLATION MANUAL

---

## **This manual includes the following documents:**

Pages 2 – 29: 52-296 BEACON POWER SUPPLY INSTALLATION INSTRUCTIONS

Pages 30 – 49: 52-350 SPS4 INSTALLATION INSTRUCTIONS

Pages 50 – 70: 52-352 MB8(F) INSTALLATION INSTRUCTIONS

## **This manual is for use with the following AlarmSaf products:**

ORDER #	MODEL #
10064	BN 6S4-004-MB16-UL
10065	BN 6S4-004-MB16F-UL
10087	BN 6S4-004-MB8-UL
10088	BN 4S4-004-MB8-UL



# **Beacon Power Supply Operating and Installation Instruction Manual**

**Model: BNx000**

## **I. Warnings and Notices**

---

- I. WARNING - To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- II. WARNING – Risk of electric shock. Installation and service should be made by qualified service personnel and should conform to all local codes.
- III. WARNING – Read the instruction manual to avoid personal injury or property damage
- IV. NOTICE - This equipment shall be installed in a manner which prevents unintentional operation from employees or other personnel working about the premises, by falling objects, by building vibration and by similar causes
- V. NOTICE - This equipment is not intended for use within the patient care areas of a Health Care Facility

## Table of Contents

Section	Page
<b>I. Warnings and Notices</b>	<b>2</b>
<b>1 Introduction</b>	<b>4</b>
<b>2 Applicable Standards / Documents</b>	<b>5</b>
<b>3 System Overview</b>	<b>6-13</b>
3.1 Electrical Ratings and Specifications	6
3.2 BNx000 Connector Descriptions and Electrical Ratings	7
3.2.1 Terminal and Connector Illustration	8
3.3 AC Input Connection	9 - 10
3.4 Accessory Board Connectors (ABC)	10
3.5 ABC Buss Voltage Selection	10-11
3.6 Output Terminals	11
3.7 FAI Input Terminals	12
3.8 Fault Reporting Terminals	13
<b>4 Installation</b>	<b>14-16</b>
4.1 Mounting	14
4.2 Wiring	15-16
<b>5 Operating the BNx000</b>	<b>17-20</b>
5.1 Output Voltage Selection	17
5.2 Jumper Settings	17-18
5.3 Visual Indicators	18-19
5.4 Troubleshooting	20
<b>6 Specifications</b>	<b>21</b>
6.1 Electrical Specifications	21
6.2 Temperature Specifications	21
6.3 Mechanical Specifications	21
Appendix A - FAI Input	22-23
Appendix B – About the Accessory Board Connector	24-26
Glossary	27

## Section 1

### Introduction

---

The Beacon Line of power supplies (BNx000) is an off-line switching power supply product line designed for use in the access control and fire industries by the Systems Integrator. They accept several accessory boards designed to increase the functionality of the basic power supply.

- Field selectable output voltage of 12V or 24VDC
- Units provide twice the current capability when set to 12VDC as at 24VDC. This is to compensate for the typically double current draw of 12V devices such as mag locks.
- Expandable with accessory boards via the ABC connector
- All units can charge up to 38AH of battery while supplying full rated load
- Full fault detection, including battery presence detection, and reporting via two form-C relay contacts; AC fault and System Fault
- Flexible FAI input for egress control or other functions. Accepts contact closure (NO or NC), voltage input, reverse polarity voltage, or open collector input
- FAI activation is transmitted to ABC connector for activation of FAI on compatible accessory boards
- Fault conditions monitored include:
  - Low or missing AC
  - High or low output / battery
  - Blown fuse
  - Missing battery
  - Reversed Battery
  - Internal Power Supply failure
- Visual indicators include:
  - AC Presence (Green)
  - DC Output Presence (Green)
  - FAI Activated (Red)
  - Reversed Battery Fault (Yellow)
  - AC Fault (Yellow)
  - System Trouble (Yellow)

## **Section 2**

### **Applicable Standards / Documents**

---

#### **NFPA Standards**

NFPA 72 National Fire Alarm Code

NFPA 70 National Electrical Code

NFPA 731 Standard for the Installation of Electronic Premises Security Systems

#### **US Standards**

UL 294 Access Control System Units

UL 1481 Power Supplies for Fire Protective Signaling System

#### **Other Standards**

MEA Listed

California State Fire Marshal (CSFM) Listed

Applicable Local and State Building Codes

Requirements of the Local Authority Having Jurisdiction (LAHJ)

#### **Other Applicable AlarmSaf Documents**

52-351: CMB8(F) Accessory Board Installation Manual

52-352: MB8(F) Accessory Board Installation Manual

52-254: APD8(F) Accessory Board Installation Manual

52-326: PD8(F) Accessory Board Installation Manual

52-350: SPS4 Accessory Board Installation Module

## Section 3

### System Overview

---

#### 3.1 Electrical Ratings and Specifications

##### Manufactured By

AlarmSaf  
6 Ledgerock Way, Unit 7  
Acton, MA 01720  
Tel: 978.658.6717; 800.987.1050  
www.alarmsaf.com

**Model Numbers (Board Only)** BN4000,  
BN6000, BN8000, BN10000; Full product list  
available at [www.alarmsaf.com](http://www.alarmsaf.com)

##### Electrical Ratings

Input Voltage	All Models: 120VAC or 240VAC nominal (with proper jumper selection, see page 18)
Input Power	BN4000: 125W maximum BN6000: 190W maximum BN8000: 250W maximum BN10000: 330W maximum
Output	12 or 24VDC nominal at: BN4000: 4A (24V out) or 8A (12V out); 110W BN6000: 6A (24V out) or 12A (12V out); 165W BN8000: 8A (24V out) or 16A (12V out); 220W BN10000: 10A (24V out) or 20A (12V out); 276W
Efficiency	~90%
Ripple	<0.5% @ 12V output
Output Fuse Type	BN4000: ATC10 (10 Amp) BN6000: ATC15 (15 Amp) BN8000: ATC20 (20 Amp) BN10000: ATC25 (25 Amp)
Buss Select Fuse Type	ATM15 (15 Amp) Miniature Automotive Blade Fuse


##### Product Use

When installed in accordance with all standards listed in Section 2 of this document, the Beacon Line provides power for use with (but not limited to) fire or access control equipment such as mag locks, door strikes, door holders, smoke dampers, four wire smoke detectors, card readers, keypads, etc.

### 3.2 BNx000 Connector Descriptions and Electrical Ratings

Terminal / Connector	Description	Rating
P1	5-Pin AC Line connector AC PWR CONNECT	102-138VAC (120VAC Nominal) or 240VAC Nominal with appropriate jumper setting (see page 18)
P2	Accessory Board Connector (ABC) Output	12 or 24VDC @ 14A Maximum or to maximum rating of power supply
TB1 - DC1 and DC2 Outputs		
DC1+	DC1 Positive Output	Full output current of supply - See Section 3.1 for ratings. Output is constant, regardless of FAI input state
DC1-	DC1 Common Output	
DC2+	DC2 Positive Output	Full output current of supply - See Section 3.1 for ratings. Output deactivates upon FAI Activation
DC2-	DC2 Common Output	
TB2 - DC3 and BAT Outputs		
DC3+	DC3 Positive Output	Full output current of supply - See Section 3.1 for ratings. Output activates upon FAI Activation
DC3-	DC3 Common Output	
BAT+	Battery Positive Connection	12 or 24VDC nominal - 38AH Maximum
BAT-	Battery Common Connection	
TB3 - FAI Input		
V+	Auxiliary Voltage Output	12VDC Nominal @ 15mA Maximum
L+	Positive FAI Activation Terminals	9-33VDC @ 15mA Maximum
L+		
L-	Common FAI Activation Terminals	
L-		
V-	Auxiliary Voltage Common	System DC Common
TB4 - Fault Contacts		
SYS FLT - COM	System Fault Relay - Common	1A @ 24VDC 0.5A @ 120VAC
SYS FLT - NC	System Fault Relay - Normally Closed	
SYS FLT - NO	System Fault Relay - Normally Open	
AC FLT - NO	AC Fault Relay - Normally Open	1A @ 24VDC 0.5A @ 120VAC
AC FLT - NC	AC Fault Relay - Normally Closed	
AC FLT - COM	AC Fault Relay - Common	





### 3.3 AC Input Connection

The AC input for the BNx000 is made through a fully shrouded pluggable cable which plugs into the AC PWR CONNECT plug (P1). The cable allows connection to either 120 VAC or 240 VAC nominal input. The BNx000 power supply must be configured for proper VAC input prior to connection or damage to the system will occur (see section 3.3.3, AC Input Safety Precautions).




Figure 3.3.1

#### 3.3.1 Configuring VAC Input

All BNx000 power supplies are factory set for 120 VAC input (102-138VAC at 50 or 60Hz). To verify **120 VAC** input setting:

- ➔ Locate the **VAC SELECT** jumper (**J5**)
- ➔ Verify that **J5** is in the **UP** position for **120 VAC** input

The BNx000 will also operate with a 240 VAC (195-264VAC at 50 or 60Hz) input. For **240 VAC** input:

- ➔ Reposition the **VAC SELECT** jumper (**J5**) in the **DOWN** position or remove it before energizing the power supply.

#### 3.3.2 Wiring the AC Input Power Cable:

The AC Input Power Cable (part #00518) is included. Connection to the harness should be made via wire nut to an appropriate power source. AC mains wiring should be no smaller than 14 AWG. Wire the cable as follows:

WIRE	FOR 120 VAC	FOR 240 VAC
Black	Line	Line 1
White	Neutral	Line 2
Green or Green/Yellow	Earth Ground	Earth Ground

### 3.3.3 AC Input Safety Precautions

- 1. CAUTION:** Verify that the main AC power is **not** energized prior to connecting the BNx000.
- 2. CAUTION:** Verify VAC Select jumper (J5) is set properly on the power supply for either 120 VAC or 240 VAC input prior to connecting the cable and energizing the power supply or damage to the system or personal property and/or injury will occur.
- 3. CAUTION:** The Green or Green/Yellow earth ground wire should always be connected first or disconnected last for safety.
- 4.** The AC input connector is a convenient and safe means for AC disconnect as the connector is fully shrouded when disconnected.
- 5.** All wiring should be installed in accordance with NEC760, NFPA70, NFPA72, and all local code requirements. See section 4.2 for more information.

### 3.4 Accessory Board Connector (P2)

#### 3.4.1 General Information

The Accessory Board Connector (ABC) supplies the output voltage and FAI control to compatible accessory boards for increased functionality including additional voltage(s), power distribution and/or power management and control for access control and fire applications. See page 26 for a list of available accessory modules. For more detailed information on the ABC expansion port, see Appendix B, "About the Accessory Board Connector".

#### 3.4.2 ABC Cable Types

Order #	Model #	Description	Used With/Notes
00519	ABC-01	6 PIN – 6 PIN, 8"	<b>1.</b> Used with BNx000 Power Supply, REV AO2 or earlier <b>2.</b> Used to interconnect EDB-10 & LDB-8 accessory boards in certain proprietary systems
00520	ABC-02	6 PIN – 6 PIN, 18"	<b>1.</b> Used with BNx000 Power Supply, REV AO2 or earlier <b>2.</b> Used to interconnect EDB-10 & LDB-8 accessory boards <b>3.</b> Increased length for connection over longer distance
00521	ABC-03	8 PIN – 8 PIN, 8"	<b>1.</b> Used with BNx000 Power Supply, REV A03A or later for connection to PD8(F), MB8(F) & CMB8(F) accessory modules
00522	ABC-04	8 PIN – 8 PIN, 18"	<b>1.</b> Used with BNx000 Power Supply, REV A03A or later for connection to PD8(F), MB8(F) & CMB8(F) accessory modules <b>2.</b> Increased length for connection over longer distance
00523	ABC-05	8 PIN – 6 PIN, 8"	<b>1.</b> Used with Bx000 Power Supply, REV A03A or later for connection to SPS4, EDB-10 & LDB-8 accessory modules
00524	ABC-06	8 PIN – 6 PIN, 18"	<b>1.</b> Used with Bx000 Power Supply, REV A03A or later for connection to SPS4, EDB-10 & LDB-8 accessory modules <b>2.</b> Increased length for connection over longer distance

**CAUTION:** The ABC-01 and ABC-02 cables are used on older BNx000 boards (PCB#: 38-118 REV A02 or earlier) that have a 6-pin ABC connector. **DO NOT USE** these cables on newer BNx000 boards (PCB # 38-118 REV A03A or later) that have an 8-pin ABC connector or damage to the system could occur.

### 3.5 ABC Voltage Selection

The output voltage of the BNx000 must be carried through the Accessory Board Connector (P2) when using the BN x000 power supply with Beacon Accessory Modules that connect to P2 using ABC cables. The Buss Select Fuse (See Figure 3.5.1.1) determines if the voltage is available on the Accessory Board Connector (P2).




Figure 3.5.1.1

#### 3.5.1 Adjusting the Buss Select Fuse

The Buss Select Fuse is factory set for proper operation. The Fuse setting options are:

SETTING/POSITION	DESCRIPTION
<b>B1 – DOWN</b>	Makes the power supply voltage available on the Accessory Board Connector (P2). This is the required setting when connecting a Beacon Accessory Module.
<b>B2 - UP</b>	Removes voltage from the Accessory Board Connector (P2).

Because older BNx000 boards (PCB#: 38-118 **REV A02** or earlier) do not have a Buss Select Fuse, always check the position of this fuse setting when installing a new BNx000 Board (PCB # 38-118 **REV A03A** or later) into an existing system.

### 3.6 Output Terminals

The BNx000 has three sets of output terminals:

- The DC1 output provides constant power, regardless of the state of the FAI input
- The DC2 output provides power which DROPS upon activation of the FAI input
- The DC3 output provides power ONLY upon activation of the FAI input

All three sets of output terminals on the BNx000 provide the same output voltage, 12VDC or 24VDC, as selected by the voltage select switch (S1). See Section 5.1 for more information.




Figure 3.6.1

**CAUTION:** Observe polarity of the BNx000 output terminals as indicated on the board with respect to the load or damage to the load may occur.

### 3.7 FAI Input Terminals

The FAI input connection for the BNx000 is made through TB3. The FAI input allows complete flexibility in connection options:

- Normally Open Contact (switching positive voltage)
- Normally Open Contact (switching DC common)
- Normally Closed Contact (Fail-Safe)
- Open collector
- Isolated or non-isolated voltage input
- Reverse Polarity voltage input
- Latching Input

There are six terminals on the BNx000 FAI input:

Terminal	Description	Use
V+	Auxiliary Voltage Output	An internal voltage source for use with dry contacts or open collectors
L+	Positive FAI Activation Terminals	These terminals are the positive input/return for the FAI loop. Only one is required for activation of the BNx000. The second is for continuing the loop for activating other devices or BNx000 supplies. Polarity is shown for activation of the
L+		
L-	Common FAI Activation Terminals	These terminals are the common input/return for the FAI loop
L-		
V-	Auxiliary Voltage Common	Common or return for the internal voltage source

See Appendix A for FAI input connection examples.




Figure 3.7.1

### 3.8 Fault Reporting Terminals

The Fault Reporting relay connection is made through TB4. Separate Form C relays are provided for AC Faults and System Faults. Connections are marked on the PCB. Six Fault terminals are available:

1. SYS FLT Common (COM)
2. SYS FLT Normally Closed (NC)
3. SYS FLT Normally Open (NO)
4. AC FLT Normally Open (NO)
5. AC FLT Normally Closed (NC)
6. AC FLT Common (COM)




Figure 3.8.1

Fault Condition	SYS FLT Relay Output	AC FLT Relay Output
Normal Condition - No Faults	No Fault	No Fault
Loss of / Low AC - Battery Charged	No Fault	Fault
Loss of / Low AC - Battery Low	Fault	Fault
Missing Battery (Battery Presence Enabled)	Fault	No Fault
High or Low Battery	Fault	No Fault
High or Low Output Voltage	Fault	No Fault
Blown AC Fuse - Battery Charged	No Fault	Fault
Blown AC Fuse - Battery Low	Fault	Fault
Blown DC1, DC2/DC3, or Battery Fuse	Fault	No Fault
Blown Buss Select Fuse	Fault	No Fault
Reversed Battery Connection	Fault	No Fault
Internal Fault	Fault	No Fault / Fault

## Section 4

### Installation

---

#### 4.1 Mounting

The BNx000 is for wall mounting only, using #8 hardware minimum in four locations. Use an appropriate fastening system for the mounting surface.

**CAUTION: Remove all power from the system before installation**

Cabinet Mounting:

1. Mark and pre-drill two holes for the top keyhole mounting screws
2. Install two fasteners in the mounting wall leaving screw heads protruding approx. ¼ inch
3. Using the two upper keyholes, mount the cabinet over the two screws
4. Mark the two lower holes, remove the cabinet and drill the lower mounting holes
5. Mount the cabinet, install the remaining fasteners, and tighten all fasteners




Figure 4.1.1

## 4.2 Wiring

### 4.2.1 Wire Routing

Wiring must be installed in accordance with NFPA70, NFPA72, and all local code requirements.

Power Limited wiring requires that power limited and non-power limited wiring remain physically separated. Any power limited circuit entering the enclosure must remain at least one quarter inch ( $\frac{1}{4}$ " ) away from any non-power limited circuit wiring. Any power limited circuit wiring must enter and exit the enclosure through different knockouts than non-power limited circuit wiring.

Wiring within the enclosure should be routed around the perimeter of the cabinet. It should not be routed across the circuit boards.

### 4.2.2 AC Input

Connection should be made via wire nut. AC mains wiring should be no smaller than 14 AWG. See Section 3.3 for details.

### 4.2.3 ABC Connector

See section 3.4

### 4.2.4 Output Wiring

Locate the output terminals to be used (DC1, DC2, or DC3). These terminals are non-removable and accept wire sizes between #12 and #22 AWG. Polarity is indicated on the PCB.

### 4.2.5 Battery Wiring

Locate the battery terminals. These terminals are non-removable and accept wire sizes between #12 and #22 AWG. Polarity is indicated on the PCB.

- For 12VDC connect one battery to the terminals
- For 24VDC connect two batteries in series to the terminals

**Note:** Connecting batteries in parallel does not allow the BNx000 to supervise the entire battery set for presence.

**CAUTION: A lead-acid battery has the capability of producing extremely high current. Personal or property damage can occur if the batteries are shorted or improperly connected.**



## **4.2 Wiring (continued)**

### **4.2.6 FAI Wiring**

Locate the FAI Input terminal block (TB3) and remove the terminal block from the header. Connect the wiring for the FAI input to the terminal block. The PC board is labeled with the connections and polarity (See also section 3.2). Replace the terminal block on the header.

### **4.2.7 Fault Relay Wiring**

Locate the Fault Relay Output terminal block (TB4) and remove the terminal block from the header. Connect the wiring for the fault outputs to the terminal block. The PC board is labeled with the connections for each relay (See also section 3.2). Replace the terminal block on the header.

**Note:** The relay is labeled in the non-powered (fault) state. Under a no-fault condition, the relay is powered (i.e. Common to Normally Open connected).

## Section 5

### Operating the BNx000

#### 5.1 Output Voltage Selection

Before powering a system containing a BNx000, the output voltage switch (S1 - Voltage Select) must be set for the proper output voltage or damage to the system could occur. Do not change the switch setting while the unit is powered or damage to the system may occur. Set the switch UP for 24V, DOWN for 12V (the PC board is labeled with the voltage settings).




Figure 5.1.1

#### 5.2 Jumper Settings

For proper operation, the jumpers on the BNx000 should be set appropriately. All jumpers should be verified or set before powering the unit.

Jumper	Description	Settings	Default
JP1 (BPD)	Battery Presence	Up (D) - Disable Down - Enable	Down - Enable
JP2 (SPV)	N/A	Up	Up
JP3 (D/E)	FAI Filtering	Left (D) - Disable Right (E) - Enable	Left (D) - Disable
J5 (VAC SELECT)	Input Voltage Configuration	Up (120) - 120VAC Input Down (240) or Removed- 240 Input	Up (120) - 120VAC
<b>Note:</b> Jumper positions are referenced with the output wiring terminal blocks (TB1&2) on the bottom			

##### 5.2.1 JP1 (BPD) - Battery Presence

Allows disabling of the battery presence detection for applications where no backup battery set is used.

##### 5.2.2 JP2 (SPV)

This jumper serves no user function and, if present, should be left in the up position.

## 5.2 Jumper Settings (continued)

### 5.2.3 JP3 (D/E)

This jumper enables or disables FAI input filtering. FAI input filtering is used if the FAI input is connected to a coded source (i.e. pulsing input).

### 5.2.4 J5 (VAC SELECT)

This jumper selects the AC input voltage to be used to power the BNx000. The power supply is factory set for 120 VAC input (J5 in the **UP** position). Move the jumper to the **DOWN** position or remove it to operate the power supply with 240 VAC input.

**CAUTION: J5 MUST be set properly before powering the unit or damage to the system will occur.**

## 5.3 Visual Indicators

The BNx000 contains seven visual status indicators:

LED	Description	Color	Conditions
AC PWR (D12)	AC Power	Green	Lights when AC Power Present
ACF (D50)	AC Fault	Yellow	Lights on low / missing AC Power
SYS TBL (D33)	System Trouble	Yellow	Lights when a system trouble present
REV BAT (D27)	Reverse Battery	Yellow	Lights when battery connection reversed
DC1 (D13)	DC1 Available	Green	Lights when DC1 output is available
DC2 / DC3 (D24)	DC2 & DC3 Available	Green	Lights when DC2 & DC3 output is available
FAI (D4)	FAI Active	Red	Lights when a valid FAI input signal is received

### 5.3.1 AC PWR (D12)

For safety reasons, this LED lights any time there is AC voltage present at the AC input, regardless of the AC fault status, battery state of charge, or power supply condition.

**CAUTION: Always check for AC presence with a volt meter before servicing**

### 5.3.2 ACF (D50)

This LED lights when AC power is low or missing. It does not necessarily indicate that the power supply is not operating. See the chart in Section 5.3.

## **5.3 Visual Indicators (continued)**

### **5.3.3 SYS TBL (D33)**

This LED lights whenever a fault condition (except AC Faults) occurs. See the chart in Section 5.3. Fault conditions detected include:

- High or Low battery voltage
- High or Low output voltage
- Internal Power Supply Fault
- Blown Fuse (F2, F3, F4)
- Missing battery (If Battery Presence is enabled)

### **5.3.4 REV BAT (D27)**

This LED lights when a battery set is connected to the BNx000 in a reverse polarity. This LED will be accompanied by the SYS TBL LED and a blown battery fuse (F4 - BAT)

### **5.3.5 DC1 (D13)**

This LED lights when there is DC power available at the DC1 output.

### **5.3.6 DC2 / DC3 (D24)**

This LED lights when there is DC power available to the DC2 and DC3 outputs.

### **5.3.7 FAI (D4)**

This LED lights when a valid FAI activation signal is received at the FAI input. When lit, the DC2 output switches OFF, the DC3 output switches ON, and the FAI buss on the ABC connector is activated for activation of compatible accessory boards.

## 5.4 Troubleshooting

Condition	Possible Cause	Solution
<b>The output voltage of the BNx000 is incorrect</b>	Incorrect switch setting	Verify proper switch setting
	Excessive loading on output	Verify that output current is less than rated current
	AC trouble	Verify presence of AC voltage
	Bad / Incorrect Battery Set	Verify that a good battery set of the proper voltage is connected to the BNx000
<b>The yellow "SYS TBL" LED (D33) is lit</b>	Blown output or battery fuse (F2, F3, or F4))	Verify all fuses are intact - Check wiring integrity before replacing fuse(s)
	Excessive loading on output	Verify that output current is less than the rated current
	Improper ABC cable connection	Verify proper connection of the ABC cable(s)
	Bad, Incorrect, or Missing Battery Set	Verify that a good battery set of the proper voltage is connected to the BNx000
	Internal problem with BNx000	Contact AlarmSaf
<b>The yellow "ACF" LED (D50) is lit</b>	Low or Missing AC	Verify the presence of at least 102VAC
	Blown AC fuse	This fuse is not replaceable in field - Contact AlarmSaf
<b>FAI LED is lit</b>	An FAI activation signal was received at the FAI input	This is normal
<b>No battery presence detection</b>	BPD Jumper (JP1) set incorrectly	Verify correct setting of BPD jumper
	No Problem	Detection of a missing battery takes 3-5 seconds
	Internal problem with BNx000	Contact AlarmSaf
<b>DC2 / DC3 has no output</b>	Check FAI Input	DC2 supplies power ONLY when the FAI input is not active. DC3 supplies power ONLY when the FAI input is active.
	Blown Fuse	Check F2
<b>No voltage on ABC and/or accessory board</b>	Incorrect Buss Select Fuse Setting	Verify proper fuse setting as described in section 3.5, page 10-11
	Blown Buss Select Fuse	Replace fuse with fuse of same type and rating

## Section 6 Specifications

### 6.1 Electrical Specifications

6.1.1 Input Voltage	120VAC or 240VAC Nominal @ 50-60Hz
6.1.2 Input Power	Model dependent - See Sec. 3.1
6.1.3 Output Voltage	12 or 24VDC Nominal
6.1.4 Output Current	Model dependent - See Sec. 3.1

### 6.2 Temperature Specifications

6.2.1 Ambient Temperature Range	0°C to 49°C (32°F to 120°F)
6.2.2 Ambient Humidity	93% at 32°C (90°F) Maximum

### 6.3 Mechanical Specifications

6.3.1 Weight (PCB Only)	2.52lbs.
6.3.2 Size (PCB Only)	8.85"L x 6.45"W x 3.10"H Max.
6.3.3 CAD Drawing	




Figure 6.3.1

## APPENDIX A, PAGE 1

### FAI Input Connection Methods


The Beacon FAI input is the most flexible we have yet seen in the industry. It may be activated by any common means found in the access and fire industry.

When activated, this input will **disable** the Beacon DC2 output and **enable** the DC3 output.

The MB8 and CMB8 accessory boards will follow the Beacon FAI input.


Methods of activation include:

1. Relay contact transfer using internal voltage source:
  - a. Normally closed.
  - b. Normally open.
2. Power from external voltage source:
  - a. Switched positive.
  - b. Switched negative.
3. Open collector connection:
  - a. Internal voltage source
  - b. External voltage.
4. Direct to NAC loop:
  - a. DC polarity reversal
  - b. DC polarity reversal with horn/strobe synchronization



## APPENDIX A, PAGE 2

### FAI Input Connection Methods (continued)






## APPENDIX B, PAGE 1

---

### About the Accessory Board Connector

The AlarmSaf Accessory Board Connector (ABC) allows plug-in system expansion using compatible AlarmSaf accessory boards. The ABC is capable of carrying both primary and secondary voltages (if applicable), DC common, fault status, and fire alarm interface status. Products can be daisy-chained together, maintaining voltage, fault, FAI, and DC common continuity throughout the chain.

**NOTE:** There are 6-pin and 8-pin versions of the ABC. The 6-pin version carries ONLY a single voltage while the 8-pin version can carry two independent voltages for dual voltage systems.



6-Pin and 8-Pin Accessory Board Connectors

**CAUTION:** The ABC-01 and ABC-02 cables are used on the older Beacon Power supply boards (PCB#: 38-118 REV A02 or earlier) that have a 6-pin ABC connector. **DO NOT USE** these cables on newer Beacon Power supply boards (PCB # 38-118 REV A03A or later) that have an 8-pin ABC connector or damage to the system could occur.

## **APPENDIX B, PAGE 2**

---

### **About the Accessory Board Connector (continued)**

#### **Voltage Busses (B1 and B2)**

The voltage busses (B1 and B2) are carried on pins 5-8 of the ABC. B1 is the primary voltage, and should typically be the higher of the two voltages in a dual voltage system. The B1 and B2 (if used) voltages are distributed through the accessory boards connected to the ABC. See the documentation for the particular accessory boards being used for details on how to utilize the B1 and/or B2 voltages. Note that 6-pin ABC connectors can carry only the B1 voltage, while 8-pin ABC connectors can carry both B1 and B2. In order for the B2 voltage to be present, a second power supply must be included in the system (AC to DC or DC to DC).

**CAUTION:** If more than one power supply is connected to any of the voltage busses, the system will not operate properly and damage to the system could occur. Verify that only one power supply is connected to each voltage buss before powering the system.

#### **Fault Status Buss**

The fault status buss carries the DC Fault status between accessory boards and power supplies. Any product with fault detection and/or reporting capability can report a fault to or from the ABC chain. Unless otherwise noted in a product's documentation, AC faults are not transmitted through the fault status buss.

Some accessory boards have a jumper to split the fault buss. This allows the separation of faults between two power supplies in some dual voltage systems. If the buss is not split, any fault on either power supply or any accessory board will show on both power supplies. If the buss is split, faults on each side of the jumper will go to their respective power supply only, allowing easier troubleshooting fault conditions, but requiring monitoring of the fault outputs of both power supplies. Note that only one split should be used in the fault status buss. See the documentation for the accessory boards in the system to determine which, if any, have a fault buss split jumper.

**NOTE:** Not all accessory boards have fault detection or reporting capability; however the fault status is still carried through these accessory boards to maintain continuity through the chain.

## APPENDIX B, PAGE 3

---

### About the Accessory Board Connector (continued)

#### Fire Alarm Interface (FAI) Status Buss

The FAI status buss carries FAI activation signals on systems utilizing a Fire Alarm Interface. This buss is used to control outputs on compatible accessory boards. See the documentation for the accessory boards in the system to determine FAI capability.

Some accessory boards have a jumper to split the FAI buss, allowing independent control of groups of accessory boards and power supplies with multiple FAI input sources. If the buss is not split, all power supplies and accessory boards with FAI capability will change state upon activation of *any* FAI input source in the chain. If the buss is split, FAI activation of any FAI input source will only activate accessory boards or power supplies up to the split. Products after the split require their own FAI input source.

**Note:** Not all accessory boards have FAI capability; however the FAI status is still carried through these accessory boards to maintain continuity through the chain.

#### DC Common

The DC Common (ground) for the system is maintained through the entire ABC chain. Any power supplies or accessory boards connected to the chain are common grounded through the ABC.

#### Accessory Boards

ACCESSORY MODULE		MODULE DESCRIPTION	ABC CABLE	
ORDER	MODEL#		ORDER	MODEL#
10041, 10042	PD8(F)	8 outputs	00521	ABC-03
10067, 10068	MB8(F)	8 outputs w/FAI & voltage selection	00521	ABC-03
10069, 10070	CMB8(F)	8 outputs w/FAI; 4 Relay Controlled	00521	ABC-03
10066	SPS4	Secondary Power Source Module: 5-18V @ 4A	00523	ABC-05
03207	FAIM	Fire Alarm Input Module (used w/PS5-M)	00521	ABC-03
97471	EDB-10	Power Distribution Module for proprietary systems	00523	ABC-05
97472	LDB-8	Power Distribution Module for proprietary systems	00523	ABC-05

## Glossary

---

ABC	See "Accessory Board Connector"
Accessory Board Connector	Connector present on some AlarmSaf power supplies and accessory boards, allowing plug-in expansion of the system
Accessory Board	An AlarmSaf product for use with AlarmSaf power supplies containing an ABC connector. These boards allow plug-in expansion of the functionality of the system. Examples of accessory boards include, but are not limited to, voltage distribution (simple and controlled), secondary DC-DC power supplies, and NAC Circuit expanders.
AC-DC Converter	A DC power supply whose voltage input is either direct from the AC line or through a step-down AC transformer
Buss 1 (B1)	The primary DC voltage in a system. Typically the higher of the two voltages in dual voltage systems
Buss 2 (B2)	The secondary DC voltage in a system. Only dual voltage systems use this voltage.
Class 2 Power Limited	A voltage output or wiring which conforms to NEC Article 725.
Controlled Distribution	Voltage distribution providing on/off control for the outputs. Control can be from FAI, an access control panel, card reader, or other device. The MB8(F) and CMB8(F) accessory boards, and the APD8(F) are examples of controlled distribution.
DC-DC Converter	A DC power supply whose voltage input comes from another DC source. DC-DC converters allow multi-voltage system backup with a single battery set.
FAI	See "Fire Alarm Interface"
Fire Alarm Interface	Input present on some AlarmSaf products allowing control of output(s) in the system. Typically used for dropping power to mag locks on egress doors during a fire alarm condition, but can also be used for other control functions, such as resetting smoke detectors
Negative Trip	An input which is activated upon the switching of a DC Common to its terminals. The DC Common may either be from an external (common grounded) source, or may be provided as one of the terminals of the input, depending on the product. This input type is used with a dry contact or open collector input.
Positive Trip	An input which is activated upon the switching of a positive DC voltage to its terminals. The positive voltage may either be from an external (common grounded) source, or may be provided as one of the terminals of the input, depending on the product. This input type is used with a dry contact or voltage input.
Power Limited	A voltage output or wiring which conforms to NEC Article 725.
PTC	A resettable overcurrent protection device, similar to a fuse or circuit breaker.
Rack Mount	A product which has an enclosure that allows mounting in a standard 19 inch equipment rack
Simple Distribution	Voltage distribution without any control function for the distributed outputs. Power is always available to the outputs. The PD8(F) accessory board is an example of simple distribution.
Voltage Distribution	Splitting a bulk power supply output into multiple, current limited outputs to prevent a single circuit failure from taking down an entire system. The multiple terminal outputs also simplify wiring by providing a pair of terminals for each circuit, rather than wiring several circuits to a single pair of terminals.



## Beacon Line Addendum A Compatible Fire Device List

The following Fire devices have been determined to be compatible with the AlarmSaf Beacon Line of power supplies. Access Control devices used must be verified for a compatible voltage range.

Manufacturer	Model	Device Type	Nominal Voltage (VDC)	Voltage Range (VDC)
Fire-Lite	2424	4-Wire Smoke	24	20-29
Fire-Lite	2424AIT	4-Wire Smoke	24	20-29
Fire-Lite	2424AT	4-Wire Smoke	24	20-29
Fire-Lite	2424TH	4-Wire Smoke	24	20-29
Fire-Lite	DH100ACDC	4-Wire Duct Smoke	24	20-29
Siemens	SDH-2D	Door Holder	24	17-31
Siemens	SDH-3D	Door Holder	24	17-31
Siemens	SDH-4D	Door Holder	24	17-31
Siemens	SDH-5D	Door Holder	24	17-31
Siemens	SDH-6D	Door Holder	24	17-31
Siemens	SDH-7D	Door Holder	24	17-31
Siemens	SDH-8D	Door Holder	24	17-31
Fire Control Instruments	FC-72 Series	Fire Alarm Control Panel	24	24



# Secondary Power Source Module Operating and Installation Instruction Manual

Model: SPS4

## I. Warnings and Notices

---

- I. WARNING - To reduce the risk of fire or electric shock, do not expose this product to rain or moisture
- II. WARNING - This installation and all servicing should be made by qualified service personnel and should conform to all local codes
- III. NOTICE - This equipment shall be installed in a manner which prevents unintentional operation from employees or other personnel working about the premises, by falling objects, by building vibration and by similar causes
- IV. NOTICE - This equipment is not intended for use within the patient care areas of a Health Care Facility

## Table of Contents

---

Section	Page
I. Warnings and Notices	2
1 Introduction	4
2 Applicable Standards / Documents	5
3 System Overview	6 - 10
3.1 Electrical Ratings and Specifications	6
3.2 SPS4 Connector Descriptions and Electrical Ratings	7
3.3 Accessory Board Connectors (ABC)	8 - 9
3.4 Output Terminals	10
4 Installation	11 - 12
4.1 Mounting	11
4.2 Wiring	12
4.3 Labeling	12
5 Operating the SPS4	13 - 14
5.1 Jumper Configuration	13
5.2 Visual Indicators	13
5.3 Troubleshooting	14
6 Specifications	15
6.1 Electrical Specifications	15
6.2 Temperature Specifications	15
6.3 Mechanical Specifications	15
Appendices:	16 - 20
Appendix A: Input Current Calculations	16
Appendix B: About the Accessory Board Connector	17 -19
Glossary	20



## Section 1

### Introduction

---

The SPS4 Secondary Power Source Module is a switching power supply board intended for use with any AlarmSaf power supply providing an ABC expansion port to supply dual voltage from a single 120 VAC input.

The SPS4 operates from a main DC power source and provides a maximum of 4 Amperes at a fixed voltage of either 5 VDC or 12 VDC or an adjustable voltage of 5 to 18 VDC. The unit has two outputs accessible by a removable terminal block, as well as an ABC expansion port output. The ABC expansion port output places the SPS4 output voltage on the B2 buss of the system while the supply used for the SPS4 input is available on the B1 buss. This allows dual voltage systems with a single backup battery to utilize dual buss accessory boards such as the MB8 and CMB8.

- Three output voltage settings: 5VDC nonadjustable, 12VDC nonadjustable, 5VDC to 18VDC adjustable
- Adjustable output allows for nonstandard voltage applications
- ABC Cables for safe and easy connection to main power supply and other accessory modules
- Two fused outputs accessible via removable terminal block
- Efficiency of >90% for extended battery life and less impact on current availability from input power supply
- Output ripple of < 0.5% for maximum range and reliability on readers
- Small size fits in typical AlarmSaf accessory board location - allows dual voltage systems in small enclosures
- Allows the use of a single battery set for dual voltage systems
- Internal fault monitoring signals the system upon detection of a fault condition
- Visual fault and status indication

## Section 2

### Applicable Standards / Documents

---

#### NFPA Standards

NFPA 72 National Fire Alarm Code

NFPA 70 National Electrical Code

NFPA 731 Standard for the Installation of Electronic Premises Security Systems

#### Other

Applicable Local and State Building Codes

Requirements of the Local Authority Having Jurisdiction (LAHJ)

#### Other Applicable AlarmSaf Documents

52-296: Beacon Power Supply Installation Manual

52-375: PS5-M Installation Manual

52-326: PD8(F) Accessory Board Installation Manual

52-351: CMB8(F) Accessory Board Installation Manual

52-352: MB8(F) Accessory Board Installation Manual

## Section 3 System Overview

---

### 3.1 Electrical Ratings and Specifications

#### **Manufactured By**

AlarmSaf  
6 Ledgerrock Way, Unit 7  
Acton, MA 01720  
Tel: 978.658.6717; 800.987.1050  
[www.alarmsaf.com](http://www.alarmsaf.com)

Model Number

SPS4

Product list available at [www.alarmsaf.com](http://www.alarmsaf.com)

#### Electrical Ratings

Input Voltage	12VDC (-30%) to 24VDC (+50%) - Must be a minimum of 3V greater than the output voltage setting at all times (including discharged battery)
Input Current	4.5A maximum - See Input Current Calculations; Page 15
Output	5VDC - 18VDC @ 4A Maximum
Efficiency	93%
Ripple	<0.5% @ 12V output
Output Fuse Type	ATM 7.5 (Automotive Mini Blade Fuse @ 7.5A)

#### Product Use

When installed in accordance with all standards listed in Section 2 of this document, the SPS4 provides a second voltage source for use with (but not limited to) fire, access control, burglar alarm, or CCTV equipment.

3.2 SPS4 Connector Descriptions and Electrical Ratings

Terminal/ Connector	Description	Rating
P1	Six-Pin ABC Connector for input or output - connects the B1 Buss only	0-24VDC Nominal at 14A (Set by B1 supply)
P2	Eight-Pin ABC connector which provides the output of the SPS4 on the B2 buss while maintaining the input power on the B1 buss	0-24VDC Nominal at 14A per supply voltage (Set by B1 supply and SPS4)
TB1	Four-Pin removable terminal block which provides a direct output for the SPS4	5-18VDC Nominal at 4A




Figure 3.2.1

### 3.3 Accessory Board Connectors (ABC)

#### 3.3.1 General Information

The ABC buss supplies the voltages (B1 and B2), fault status, and FAI control to compatible accessory boards. On the SPS4, the B1 voltage (which is also the input to the SPS4) is carried through P1 and P2, while the B2 voltage (the output of the SPS4) is carried through P2. By using the appropriate cables, the SPS4 can be connected to other accessory boards in the system for voltage distribution of both busses. Typically P1 should be used for voltage input, while P2 should be used for the dual buss output. For more detailed information on the AlarmSaf ABC expansion port, see Appendix B, "About the Accessory Board Connector".

#### 3.3.2 ABC Cable Types

Order #	Model #	Description	Used With/Notes
00519	ABC-01	6 PIN – 6 PIN, 8"	1. Used with BNx000 Power Supply, REV A02 or earlier 2. Used to interconnect EDB-10 & LDB-8 accessory boards in certain proprietary systems
00520	ABC-02	6 PIN – 6 PIN, 18"	1. Used with BNx000 Power Supply, REV A02 or earlier 2. Used to interconnect EDB-10 & LDB-8 accessory boards 3. Increased length for connection over longer distance
00521	ABC-03	8 PIN – 8 PIN, 8"	1. Used with BNx000 Power Supply, REV A03A or later and PS5-M for connection to PD8(F), MB8(F) & CMB8(F) accessory modules
00522	ABC-04	8 PIN – 8 PIN, 18"	1. Used with BNx000 Power Supply, REV A03A or later and PS5-M for connection to PD8(F), MB8(F) & CMB8(F) accessory modules 2. Increased length for connection over longer distance
00523	ABC-05	8 PIN – 6 PIN, 8"	1. Used with Bx000 Power Supply, REV A03A and PS5-M or later for connection to SPS4, NAC, EDB-10 & LDB-8 accessory modules
00524	ABC-06	8 PIN – 6 PIN, 18"	1. Used with Bx000 Power Supply, REV A03A and PS5-M or later for connection to SPS4, NAC, EDB-10 & LDB-8 accessory modules 2. Increased length for connection over longer distance

CAUTION: The ABC-01 and ABC-02 cables are used on older BNx000 boards (PCB#: 38-118 REV A02 or earlier) that have a 6-pin ABC connector. **DO NOT USE** these cables on newer BNx000 boards (PCB # 38-118 REV A03A or later) that have an 8-pin ABC connector or damage to the system could occur.

### 3.3 Accessory Board Connectors (ABC) (continued)

#### 3.3.3 Connecting an SPS4 to an AlarmSaf Power Supply

The SPS4 board is supplied with an ABC-05 cable (see chart in section 3.3.2). This cable allows connection of the 6-pin P1 ABC connector of the SPS4 to an AlarmSaf power supply with an 8-pin ABC connector. The 8-pin P2 ABC connector of the SPS4 is used for connection to other accessory boards in the system for voltage distribution of both busses.

##### 3.3.3.1 Connecting the SPS4 to an AlarmSaf BNx000 Power Supply Board

1. Remove the power from the system
2. Verify that the Buss Select Fuse on the BNx000 is in the B1 position (see BNx000 Installation Manual, document #52-296 for more information) or the system will not operate properly and damage to the SPS4 could occur.
3. Verify voltage settings on the BNx000 and the SPS4 before powering the system. See table in section 3.3.3.3 for dual output voltage configuration.
4. Connect the 8-pin ABC cable to the 8-pin ABC on the BNx000  
NOTE: Earlier versions of the BNx000 Power Supply used a 6-pin ABC. A different cable is required. Contact AlarmSaf for the appropriate cable.
5. Connect the 6-pin ABC cable to the 6-pin P1 ABC on the SPS4

##### 3.3.3.2 Connecting the SPS4 to an AlarmSaf PS5-M Power Supply Board

1. Remove the power from the system
2. Verify that the Buss Select Fuse on the PS5-M is in the B1 position (see PS5-M Installation Manual, document #52-375 for more information) or the system will not operate properly and damage to the SPS4 could occur.
3. Verify voltage settings on the PS5-M and the SPS4 before powering the system. See table in section 3.3.3.3 for dual output voltage configuration.
4. Connect the 8-pin ABC connector to the PS5-M
5. Connect the 6-pin ABC connector to the SPS4

##### 3.3.3.3 Voltage Settings for Dual Voltage Operation using the SPS4

BNx000 or PS5-M Output Voltage	SPS4 Output Voltage*
24 VDC	5 VDC Fixed or 12 VDC Fixed or 5 – 18 VDC adjustable
12 VDC	5 VDC Fixed

\* See Section 5.1 for jumper settings

### 3.4 Output Terminals

The SPS4's output terminals (TB1) provide power from the supply and each terminal accepts a 22-14 AWG wire. Both outputs are protected by a single common ATM-7.5 fuse.

**CAUTION:** Observe the polarity of the SPS4 output terminals with respect to the load or damage to the load may occur.

**CAUTION:** Before powering the system with any outputs connected, verify that the output voltage and all jumpers are properly set or damage to the system could occur.




Figure 3.4.1

## Section 4 Installation

---

### 4.1 Mounting

The SPS4 mounts in the accessory board space on a power supply or to the back of a metal enclosure.

**CAUTION:** Remove all power from the system before installation

#### 4.1.1 Mounting On a Power Supply

1. Remove and save the four mounting screws from the accessory board mounting space on the power supply, if present.
2. If screws were removed, install 6-32 x 1 1/4" Male-Female standoffs in the four locations where the screws were removed (the aluminum standoff, if present, is installed in the top left mounting hole).
3. If screws were not removed, install 6-32 x 3/4" Female-Female nylon standoffs on the appropriate mounting holes on the Power Supply board (the aluminum standoff, if present, is installed on the top left mounting hole), using four of the included 6-32 x 3/8" screws from the bottom of the Power Supply.
4. Mount the SPS4 to the standoffs using four of the 6-32 x 3/8" screws.
5. Connect ABC cable(s) appropriately (See section 3.3)

#### 4.1.2 Mounting In a Metal Enclosure

1. Install four 6-32 x 3/4" Female-Female nylon standoffs on the appropriate mounting studs in the enclosure (the aluminum standoff, if present, is installed on the top left mounting stud).
2. Mount the SPS4 to the standoffs using 6-32 x 3/8" screws.
3. Connect ABC cable(s) appropriately (See section 3.3)




Figure 4.1.1



## 4.2 Wiring

### 4.2.1 Wire Routing

All wiring must be installed in accordance with NFPA70 [NEC760], NFPA72, and all local code requirements.

Power Limited wiring requires that power limited and non-power limited wiring remain physically separated. Any power limited circuit entering the enclosure must remain at least one quarter inch ( $\frac{1}{4}$ " ) away from any non-power limited circuit wiring. Any power limited circuit wiring must enter and exit the enclosure through different knockouts than non-power limited circuit wiring.

Wiring within the enclosure should be routed around the perimeter of the cabinet. It should not be routed across the circuit boards.

### 4.2.2 ABC Connector

See section 3.3

### 4.2.3 Output Wiring (Optional)

Locate the output wiring terminal block (TB1) on the PC board and remove the terminal block from the header. Connect the wiring for the equipment to be powered to the terminal block. The PC board is labeled with the output numbers and polarity (See also Sections 3.2 and 3.4). Replace the terminal block on the header.

NOTE: Wire size for these terminals must be 22-14 AWG.

## 4.3 Labeling

If the SPS4 was purchased separately from the power supply unit, the supplied label must be applied to the inside cover of the power supply's enclosure. The label shall not cover any ventilation holes or other labeling on the enclosure.

## Section 5

### Operating the SPS4

#### 5.1 Jumper Configuration

Before powering a system containing an SPS4, the jumpers must be set for proper operation. Do not change jumper settings while the unit is powered or damage to the system may occur.




Figure 5.1.1

Output Voltage	JP1	JP2	Note
5 VDC Fixed Voltage	Left	Left	
12 VDC Fixed Voltage	Left	Right	Factory Default Setting
5-18 VDC Adjustable Voltage	Right	Left	Adjust Potentiometer
<i>Note: Jumper positions are referenced with the output wiring terminal block (TB1) on the bottom</i>			

**CAUTION:** When using the adjustable output setting of the SPS4, do not connect the system load (including P2) until the output voltage is adjusted or damage to the system may occur.

#### 5.2 Visual Indicators

The SPS4 has three visual indicators:

LED	Description	Color	Conditions
DC IN (D7)	DC Input	Green	Lights when DC voltage is present on the input
DC OUT (D8)	DC Output	Green	Lights when DC voltage is present on the output
FLT (D6)	Fault	Yellow	Lights when the SPS4 detects a fault condition

##### 5.2.1 DC IN

This LED illuminates whenever there is DC voltage present on the input of the SPS4.

##### 5.2.2 DC OUT

This LED illuminates when DC voltage is available at the outputs of the SPS4.

##### 5.2.3 FLT

This LED illuminates if the DC output of the SPS4 goes either high or low or if the output fuse F1) ruptures.

### 5.3 Troubleshooting

Condition	Possible Cause	Solution
The output voltage of the SPS4 is incorrect or missing	Incorrect jumper settings	Verify proper jumper settings
	Incorrect potentiometer setting (adjustable output range only)	Adjust potentiometer to obtain proper output voltage
	Excessive loading on output	Verify that output current is less than 4A
	Insufficient input voltage	Verify input voltage is at least 3 volts greater than the desired output
	Insufficient input current available	Verify that the input power supply has enough current capability to power its output load plus the SPS4
	Incorrect Buss Select Fuse setting on connected BNx000 Power Supply	Verify proper fuse setting - see section 3.3.3.1
	Incorrect ABC Cable	Check ABC Cable – see section 3.3
The yellow “FLT” LED (D6) is lit	Blown output fuse (F1)	Verify fuse is intact
	Excessive loading on output	Verify that output current is less than 4A
	Improper ABC cable connection	Verify proper connection of the ABC cable(s)
	Insufficient input voltage	Verify input voltage is at least 3 volts greater than the desired output
	Insufficient input current available	Verify that the input power supply has enough current capability to power its output load plus the SPS4
	Internal problem with SPS4	Contact AlarmSaf
There are no LEDs lit	Problem with input power supply	Verify proper operation of the power supply used to power the SPS4
	Improper or missing ABC cable connection	Verify proper connection of the ABC cable(s)
	Faulty ABC cable	Verify continuity of all conductors
	Internal problem with SPS4	Contact AlarmSaf

## Section 6 Specifications

### 6.1 Electrical Specifications

6.1.1 Input Voltage (B1)	12VDC (-30%) to 24VDC (+50%) Nominal (must be at least 3V greater than output)
6.1.2 Input Current (B1)	4.5A maximum (See Appendix A)
6.1.3 Output Voltage (B2)	5-18VDC
6.1.4 Output Current (B2)	4A maximum
6.1.5 Output Ripple	<0.5% @ 12V output

### 6.2 Temperature Specifications

6.2.1 Ambient Temperature Range	0°C to 49°C (32°F to 120°F)
6.2.2 Ambient Humidity	93% at 32°C (90°F) Maximum

### 6.3 Mechanical Specifications

6.3.1 Weight	0.24 Lbs (Not including hardware or cables)
6.3.2 Size	4.80"L x 2.35"W x 1.10"H NOTE: Width includes terminal block overhang of 0.10"
6.3.3 CAD Drawing	




Figure 6.3.1

## APPENDIX A

### Input Current Calculations

The most accurate method for calculating input current is to calculate the output power, divide it by the efficiency, and add a safety margin.

$$I_{IN} = ((V_{OUT} * I_{OUT} * M) / E) * (1 / V_{IN})$$

Where:

$I_{OUT}$  = Output Current in Amps

$V_{OUT}$  = Actual Output Voltage in Volts

E = Efficiency (Typically 90%)

M = Safety Margin (Typically 110%)

$V_{IN}$  = Actual Input Voltage


Example:

2A output @ 15.3V output; 27.6V Input

$$I_{IN} = ((15.3V * 2A * 1.1) / .9) * (1 / 27.6V)$$

$$I_{IN} = 1.4A$$

If only a general idea of input current is needed, calculate the ratio of input voltage to output voltage ( $V_{IN} / V_{OUT}$ ) and use the chart below. Choose the output current closest to your actual output current.




## APPENDIX B, PAGE 1

---

### About the Accessory Board Connector

The AlarmSaf Accessory Board Connector (ABC) allows plug-in system expansion using compatible AlarmSaf accessory boards. The ABC is capable of carrying both primary and secondary voltages (if applicable), DC common, fault status, and fire alarm interface status. Products can be daisy-chained together, maintaining voltage, fault, FAI, and DC common continuity throughout the chain.

NOTE: There are 6-pin and 8-pin versions of the ABC. The 6-pin version carries ONLY a single voltage while the 8-pin version can carry two independent voltages for dual voltage systems.



6-Pin and 8-Pin Accessory Board Connectors

**CAUTION:** The ABC-01 and ABC-02 cables are used on the older Beacon Power supply boards (PCB#: 38-118 REV A02 or earlier) that have a 6-pin ABC connector. **DO NOT USE** these cables on newer Beacon Power supply boards (PCB # 38-118 REV A03A or later) that have an 8-pin ABC connector or damage to the system could occur.

## APPENDIX B, PAGE 2

---

### About the Accessory Board Connector (continued)

#### Voltage Busses (B1 and B2)

The voltage busses (B1 and B2) are carried on pins 5-8 of the ABC. B1 is the primary voltage, and should typically be the higher of the two voltages in a dual voltage system. The B1 and B2 (if used) voltages are distributed through the accessory boards connected to the ABC. See the documentation for the particular accessory boards being used for details on how to utilize the B1 and/or B2 voltages. Note that 6-pin ABC connectors can carry only the B1 voltage, while 8-pin ABC connectors can carry both B1 and B2. In order for the B2 voltage to be present, a second power supply must be included in the system (AC to DC or DC to DC).

**CAUTION:** If more than one power supply is connected to any of the voltage busses, the system will not operate properly and damage to the system could occur. Verify that only one power supply is connected to each voltage buss before powering the system.

#### Fault Status Buss

The fault status buss carries the DC Fault status between accessory boards and power supplies. Any product with fault detection and/or reporting capability can report a fault to or from the ABC chain. Unless otherwise noted in a product's documentation, AC faults are not transmitted through the fault status buss.

Some accessory boards have a jumper to split the fault buss. This allows the separation of faults between two power supplies in some dual voltage systems. If the buss is not split, any fault on either power supply or any accessory board will show on both power supplies. If the buss is split, faults on each side of the jumper will go to their respective power supply only, allowing easier troubleshooting fault conditions, but requiring monitoring of the fault outputs of both power supplies. Note that only one split should be used in the fault status buss. See the documentation for the accessory boards in the system to determine which, if any, have a fault buss split jumper.

**NOTE:** Not all accessory boards have fault detection or reporting capability; however the fault status is still carried through these accessory boards to maintain continuity through the chain.

## APPENDIX B, PAGE 3

---

### About the Accessory Board Connector (continued)

#### Fire Alarm Interface (FAI) Status Buss

The FAI status buss carries FAI activation signals on systems utilizing a Fire Alarm Interface. This buss is used to control outputs on compatible accessory boards. See the documentation for the accessory boards in the system to determine FAI capability.

Some accessory boards have a jumper to split the FAI buss, allowing independent control of groups of accessory boards and power supplies with multiple FAI input sources. If the buss is not split, all power supplies and accessory boards with FAI capability will change state upon activation of *any* FAI input source in the chain. If the buss is split, FAI activation of any FAI input source will only activate accessory boards or power supplies up to the split. Products after the split require their own FAI input source.

Note: Not all accessory boards have FAI capability; however the FAI status is still carried through these accessory boards to maintain continuity through the chain.

#### DC Common

The DC Common (ground) for the system is maintained through the entire ABC chain. Any power supplies or accessory boards connected to the chain are common grounded through the ABC.

#### Accessory Boards


ACCESSORY MODULE		MODULE DESCRIPTION	ABC CABLE	
ORDER	MODEL#		ORDER	MODEL#
10041, 10042	PD8(F)	8 outputs	00521	ABC-03
10067, 10068	MB8(F)	8 outputs w/FAI & voltage selection	00521	ABC-03
10069, 10070	CMB8(F)	8 outputs w/FAI; 4 Relay Controlled	00521	ABC-03
10066	SPS4	Secondary Power Source Module: 5-18V @ 4A	00523	ABC-05
03207	FAIM	Fire Alarm Input Module (used w/PS5-M)	00521	ABC-03
97471	EDB-10	Power Distribution Module for proprietary systems	00523	ABC-05
97472	LDB-8	Power Distribution Module for proprietary systems	00523	ABC-05



## Glossary

---

ABC	See "Accessory Board Connector"
Accessory Board Connector	Connector present on some AlarmSaf power supplies and accessory boards, allowing plug-in expansion of the system
Accessory Board	An AlarmSaf product for use with AlarmSaf power supplies containing an ABC connector. These boards allow plug-in expansion of the functionality of the system. Examples of accessory boards include, but are not limited to, voltage distribution (simple and controlled), secondary DC-DC power supplies, and NAC Circuit expanders.
AC-DC Converter	A DC power supply whose voltage input is either direct from the AC line or through a step-down AC transformer
Buss 1 (B1)	The primary DC voltage in a system. Typically the higher of the two voltages in dual voltage systems
Buss 2 (B2)	The secondary DC voltage in a system. Only dual voltage systems use this voltage.
Class 2 Power Limited	A voltage output or wiring which conforms to NEC Article 725.
Controlled Distribution	Voltage distribution providing on/off control for the outputs. Control can be from FAI, an access control panel, card reader, or other device. The MB8(F) and CMB8(F) accessory boards, and the APD8(F) are examples of controlled distribution.
DC-DC Converter	A DC power supply whose voltage input comes from another DC source. DC-DC converters allow multi-voltage system backup with a single battery set.
FAI	See "Fire Alarm Interface"
Fire Alarm Interface	Input present on some AlarmSaf products allowing control of output(s) in the system. Typically used for dropping power to maglocks on egress doors during a fire alarm condition, but can also be used for other control functions, such as resetting smoke detectors
Negative Trip	An input which is activated upon the switching of a DC Common to its terminals. The DC Common may either be from an external (common grounded) source, or may be provided as one of the terminals of the input, depending on the product. This input type is used with a dry contact or open collector input.
Positive Trip	An input which is activated upon the switching of a positive DC voltage to its terminals. The positive voltage may either be from an external (common grounded) source, or may be provided as one of the terminals of the input, depending on the product. This input type is used with a dry contact or voltage input.
Power Limited	A voltage output or wiring which conforms to NEC Article 725.
PTC	A resettable overcurrent protection device, similar to a fuse or circuit breaker.
Rack Mount	A product which has an enclosure that allows mounting in a standard 19 inch equipment rack
Simple Distribution	Voltage distribution without any control function for the distributed outputs. Power is always available to the outputs. The PD8(F) accessory board is an example of simple distribution.
Voltage Distribution	Splitting a bulk power supply output into multiple, current limited outputs to prevent a single circuit failure from taking down an entire system. The multiple terminal outputs also simplify wiring by providing a pair of terminals for each circuit, rather than wiring several circuits to a single pair of terminals.



# Model MB8(F)

## Multi-Buss Distribution Board

Operating and Installation Instructions

## I. Warnings and Notices

---

- I. WARNING - To reduce the risk of fire or electric shock, do not expose this product to rain or moisture
- II. WARNING - This installation and all servicing should be made by qualified service personnel and should conform to all local codes
- III. NOTICE - This equipment shall be installed in a manner which prevents unintentional operation from employees or other personnel working about the premises, by falling objects, by building vibration and by similar causes
- IV. NOTICE - This equipment is not intended for use within the patient care areas of a Health Care Facility

## Table of Contents

---

Section	Page
I Warnings and Notices	2
1 Introduction	4
2 Applicable Standards / Documents	5
3 System Overview	6 - 10
3.1 Electrical Ratings and Specifications	6
3.2 MB8(F) Terminal and Connector Descriptions and Electrical Ratings	7
3.3 ABC Connectors and Harnesses	8-9
3.4 Output Terminals	10
4 Installation	11 - 12
4.1 Mounting	11
4.2 Wiring	12
4.3 Labeling	12
5 Operating the MB8(F)	13 - 15
5.1 Jumper Configuration	13 - 14
5.2 Visual Indicators	15
5.3 Troubleshooting	15
6 Specifications	16
6.1 Electrical Specifications	16
6.2 Temperature Specifications	16
6.3 Mechanical Specifications	16
Appendices:	17 - 21
Appendix A: Sample Applications	17
Appendix B: About the Accessory Board Connector	18 -20
Glossary	21

## Section 1

### Introduction

---

The MB8(F) Multi-Buss Distribution board provides eight individually configurable outputs to any AlarmSaf power supply or accessory board with an ABC expansion port. It accepts inputs from one or two independent voltage sources, either of which is available at any output by jumper selection. Egress control is individually selectable by output for continuous power, activate on fire alarm, or disable on fire alarm. Fire alarm control is provided through the base power supply's FAI input.

- Eight Individually Configurable Outputs
- Available with Class-2 Power Limited outputs (MB8) or Fused (non-power limited) outputs (MB8F)
- One or two independent voltage inputs for dual voltage systems, or increased current capability in a single voltage system
- Each output is configurable for either voltage source and FAI control by simple jumper selection
- Each output is capable of supplying up to 3A (MB8F) or 1.6A (MB8) up to the maximum current capability of each voltage source
- Fused versions use easily obtainable ATM-3 automotive miniature blade fuses

## Section 2

### Applicable Standards / Documents

---

#### NFPA Standards

NFPA 72 National Fire Alarm Code

NFPA 70 National Electrical Code

NFPA 731 Standard for the Installation of Electronic Premises Security Systems

#### US Standards

UL 294 Access Control System Units

UL 1481 Power Supplies for Fire Protective Signaling System

UL 1076 Proprietary Burglar Alarm Units and Systems

UL 2044 Commercial Closed-Circuit Television Equipment

#### Canadian Standards

ULC S527 Standard for Control Units for Fire Alarm Systems

ULC S318 Standard for Power Supplies for Burglar Alarm Systems

CAN/CSA-C22.2 No. 107.1-01 General Use Power Supplies

#### Other

Applicable Local and State Building Codes

Requirements of the Local Authority Having Jurisdiction (LAHJ)

#### Other Applicable AlarmSaf Documents

52-296: Beacon Power Supply Instruction Manual

#### Listing Compliance Note

This product carries an ETL Listing from Intertek for one or more of the standards listed above. Intertek is recognized by the Occupational Safety and Health Administration (OSHA) as a Nationally Recognized Testing Laboratory (NRTL) and accredited by the Standards Council of Canada as a Testing Organization and Certifying Body. The ETL Listed Mark is recognized, acknowledge and accepted by local inspectors and Authorities Having Jurisdiction (AHJs) throughout North America as an accepted alternative to UL and as proof of product compliance. For more information about the NRTL program, we encourage you to visit the OSHA Web site at [www.osha.gov](http://www.osha.gov).

## Section 3

### System Overview

---

#### 3.1 Electrical Ratings and Specifications

##### **Manufactured By**

AlarmSaf  
6 Omni Way  
Chelmsford, MA 01824-4141  
Tel: 978.658.6717; 800.987.1050  
[www.alarmsaf.com](http://www.alarmsaf.com)

##### Model Numbers

MB8, MB8F

##### Electrical Ratings

Inputs	Two Inputs: 0-24VDC Nominal @ 14 Amps maximum per input
Outputs	Eight Outputs: 1.6A (MB8) or 3A (MB8F) per output up to the maximum capability of each base power supply. Output voltages determined by base power supplies and jumper selections
Fuse Type (MB8F only)	ATM-3 Automotive Miniature Blade-type

##### Product Use

When installed in accordance with all standards listed in Section 2 of this document and used with an appropriate listed supply, the MB8(F) provides constant or FAI controlled outputs, sourced from one of two voltage sources for powering devices such as (but not limited to) Mag Locks, Door Strikes, Card Readers, Smoke Dampers, 4-Wire Smoke detectors, etc.

### 3.2 MB8(F) Terminal and Connector Descriptions and Electrical Ratings

Terminal / Connector	Description	Rating
P1	ABC Input or Output	0-24V Nominal at 14A per Buss (controlled by base supply(s))
P2	ABC Input or Output	
TB1 - Outputs 1 through 4		
Out1 +	Output 1 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out1 -	Output 1 -	
Out2 +	Output 2 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out2 -	Output 2 -	
Out3 +	Output 3 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out3 -	Output 3 -	
Out4 +	Output 4 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out4 -	Output 4 -	
TB2 - Outputs 5 through 8		
Out5 +	Output 5 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out5 -	Output 5 -	
Out6 +	Output 6 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out6 -	Output 6 -	
Out7 +	Output 7 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out7 -	Output 7 -	
Out8 +	Output 8 +	1.6A (MB8) or 3A (MB8F) maximum - Voltage determined by base supplies and jumper selection
Out8 -	Output 8 -	




Figure 3.2.1



### 3.3 ABC Connectors and Harnesses

#### 3.3.1 General Information

The ABC buss supplies the voltages (B1 and B2), fault status and FAI control to compatible accessory boards. B1 is supplied through pins 5 and 6 while B2, if used, is supplied through pins 7 and 8 of each connector. By using the appropriate cables, one or two independent voltage sources can be connected to the MB8(F) for distribution to its outputs. For more detailed information on the AlarmSaf ABC expansion port, see Appendix B, "About the Accessory Board Connector".

Note: If the FAI function is to be used, one of the voltage busses (B1 or B2) **MUST** be 12V or higher

#### 3.3.2 Single Voltage Distribution

A single power source can be connected to the MB8(F) by using an 8-6 cable (Order # 00523 or 00524) connected to pins 1 through 6 of one of the ABC connectors (P1 or P2).

#### 3.3.3 Dual Voltage Distribution

3.3.3.1: If both source voltages are present on the ABC buss, use an 8-8 cable (Order # 00521 or 00522) connected to either ABC Connector on the MB8(F) to provide both B1 and B2.

3.3.3.2: If two independent power supplies are used, use one 8-6 cable (Order #00523 or 00524) from the first power supply to either ABC connector (P1 or P2) on the MB8(F) for B1 and one 8-6 cable (Order #00523 or 00524) from the second power supply to the other ABC connector (P1 or P2) on the MB8(F) for B2.

### 3.3.4 ABC Cable Types

Cable Type	Order #	Description	Length	Notes
6-6	00519	ABC-01	8 inches	Used with Beacon Power supply REV A02 or earlier ONLY
6-6	00520	ABC-02	18 inches	Used with Beacon Power supply REV A02 or earlier ONLY
8-8	00521	ABC-03	8 inches	Brown wire identifies Pin 1
8-8	00522	ABC-04	18 inches	Brown wire identifies Pin 1
8-6	00523	ABC-05	8 inches	Brown wire identifies Pin 3 on the 8 connector end & Pin 1 on the 6 connector end
8-6	00524	ABC-06	18 inches	Brown wire identifies Pin 3 on the 8 connector end & Pin 1 on the 6 connector end

ABC-01: Used to connect a 6-pin ABC Beacon power supply to the first accessory board when the accessory board is located close to power supply.\*

ABC-02: Used to connect a 6-pin ABC Beacon power supply to the first accessory board, when the accessory board is not located close to power supply.\*

ABC-03: Used to connect the 8-pin ABC Beacon power supply accessory board to the first accessory board or to connect accessory board to accessory board over short distances.

ABC-04: Used to connect the 8-pin ABC Beacon power supply accessory board to the first accessory board or to connect accessory board to accessory board over long distances.

ABC-05: Short cable used to connect 8-pin ABC Beacon Power Supply to a 6-pin ABC accessory board such as the SPS4.

ABC-06: Long cable used to connect 8-pin ABC Beacon Power Supply to a 6-pin ABC accessory board such as the SPS4.

\* **NOTE:** The ABC-01 and ABC-02 cables are used only on the older Beacon Power supply boards (PCB#: 38-118 REV A02 or earlier) that have a 6-pin ABC connector. **DO NOT USE** these cables on newer Beacon Power supply boards (PCB # 38-118 REV A03A or later) with 8-pin ABC connector boards or damage to the system could occur.

### 3.4 Output Terminals

The MB8(F)'s output terminals (TB1 and TB2) provide power distributed from the B1 and B2 (if present) supplies. The voltage source and FAI activation selections for each output are made through each output's configuration jumper settings. See Section 5 for configuration jumper settings.

Each output is protected by either an ATM-3 fuse (MB8F) or a 1.6A PTC (MB8). If an output PTC is tripped, remove the output load by either removing the output wiring or by pulling the output's configuration jumper (note it's position before removing) for 30 seconds.

**CAUTION:** Observe the polarity of the MB8(F) output terminals with respect to the load or damage to the load may occur.




Figure 3.4.1

## Section 4 Installation

---

### 4.1 Mounting

The MB8(F) mounts either in the accessory board space on the power supply or to the back of a metal enclosure.

**CAUTION:** Remove all power from the system before installation

#### 4.1.1 Mounting On a Power Supply

1. Remove and save the four mounting screws from the accessory board mounting space on the power supply.
2. Install 6-32 x 1 1/4" Male-Female standoffs in the four locations where the screws were removed (the aluminum standoff, if present, is installed in the top left mounting hole).
3. Mount the MB8(F) to the standoffs using the screws removed in step 1
4. Connect ABC cable(s) appropriately (See section 3.3)

#### 4.1.2 Mounting In a Metal Enclosure

1. Install four 6-32 x 3/4" Female-Female nylon standoffs on the appropriate mounting studs in the enclosure (the aluminum standoff, if present, is installed on the top left mounting stud).
2. Mount the MB8(F) to the standoffs using 6-32 x 3/8" screws.
3. Connect ABC cable(s) appropriately (See section 3.3)




Figure 4.1.1

## 4.2 Wiring

### 4.2.1 Wire Routing

All wiring must be installed in accordance with NFPA70 [NEC760], NFPA72, and all local code requirements.

Power Limited wiring requires that power limited and non-power limited wiring remain physically separated. Any power limited circuit entering the enclosure must remain at least one quarter inch ( $\frac{1}{4}$ " ) away from any non-power limited circuit wiring. Any power limited circuit wiring must enter and exit the enclosure through different knockouts than non-power limited circuit wiring.

Wiring within the enclosure should be routed around the perimeter of the cabinet. It should not be routed across the circuit boards. See the enclosure's documentation for complete wire routing instructions.

### 4.2.2 ABC Connector

See section 3.3

### 4.2.3 Output Wiring

Locate the output wiring terminal blocks (TB1 and TB2) and remove the terminal block from the header. Connect the wiring for the equipment to be powered to the terminal block. The PC board is labeled with the output numbers and polarity (See also section 3.2). Replace the terminal block on the header.

NOTE: Wire size for these terminals must be 22-14 AWG.

## 4.3 Labeling

If the MB8(F) was purchased separately from the power supply unit, the supplied label must be applied to the inside cover of the power supply's enclosure. The label shall not cover any ventilation holes or other labeling on the enclosure.

## Section 5

### Operating the MB8(F)

---

#### 5.1 Jumper Configuration

Before powering a system containing an MB8(F), the jumpers must be set for proper operation. Failure to do so before applying power could damage the system.

Jumper	Description	Settings	Factory Default
JP1 - JP8	Output Voltage and FAI Control	1 (CB2) - B2 Constant 2 (EB2) - B2 Enable on FAI 3 (DB2) - B2 Disable on FAI 4 (CB1) - B1 Constant 5 (EB1) - B1 Enable on FAI 6 (DB1) - B1 Disable on FAI	CB1
JP9	FAI Buss Join	Up - FAI Connected between P1 & P2 Down - FAI NOT connected between P1 & P2	Down
JP10	Fault Buss Join	Up - Fault Buss connected between P1 & P2 Down - Fault Buss NOT connected between P1 & P2	Down

##### 5.1.1 Output Voltage and FAI Control (JP1 through JP8)

These jumpers select the voltage source (B1 or B2 - See section 3.3) and FAI mode for each output. Jumper positions are numbered with position one being at the top (farthest away from the output terminals), and position six being at the bottom. Reference nomenclature is also provided on the PC board to the left of P1.

- Position 1 (CB2) - Constant power from the B2 buss is provided at the output. No action is performed when the system's FAI input is activated.
- Position 2 (EB2) - Power from the B2 buss is provided when the system's FAI input is activated.
- Position 3 (DB2) - Power from the B2 buss is provided when the system's FAI input is NOT active. Power to the output is dropped upon activation of the FAI input.
- Position 4 (CB1) - Constant power from the B1 buss is provided at the output. No action is performed when the system's FAI input is activated.
- Position 5 (EB1) - Power from the B1 buss is provided when the system's FAI input is activated.
- Position 6 (DB1) - Power from the B1 buss is provided when the system's FAI input is NOT active. Power to the output is dropped upon activation of the FAI input.

## 5.1 Jumper Configuration (continued)

### 5.1.2 FAI Buss Join (JP9)

Placing this jumper in the “up” position connects the FAI buss between P1 and P2. If two separate power supplies are connected to P1 and P2, BOTH will activate on an FAI input on either supply. This jumper should also be in the “up” position when one connector (P1 or P2) is used for power input, and the other connector is used as an output for further expansion.

Placing JP9 in the “down” position disconnects P1 from the FAI buss on the MB8(F). FAI activation of the MB8(F) MUST be performed through the supply connected to P2. An FAI activation on P1 will have no effect on the MB8(F) with JP9 down.

### 5.1.3 Fault Buss Join (JP10)

Placing this jumper in the “up” position connects the fault buss between P1 and P2. If two separate power supplies are connected to P1 and P2, BOTH will show a trouble with a trouble on either supply. This jumper should also be in the “up” position when one connector (P1 or P2) is used for power input, and the other connector is used as an output for further expansion.

Placing JP10 in the “down” position disconnects P1 from the fault buss on the MB8(F). This is useful if separation of faults between two supplies is desired.




Figure 5.1.1

## 5.2 Visual Indicators

The MB8(F) has three LEDs to indicate status:

- Buss Voltage 1 - Indicates that voltage is present on the B1 buss when lit
- Buss Voltage 2 - Indicates that voltage is present on the B2 buss when lit
- FAI - Indicates that MB8(F) is receiving an FAI signal from the power supply(s) when lit




Figure 5.2.1

## 5.3 Troubleshooting

Condition	Possible Cause	Solution
No voltage on output	Jumper settings incorrect	Verify proper jumper settings
	Missing jumper	Verify jumper present
	No voltage supply	Verify the power supply
	Blown output fuse (MB8F)	Check output wiring and replace fuse
	Tripped output PTC (MB8)	Check output wiring and remove load for 30 seconds to reset
Incorrect voltage on output	Incorrect voltage buss selected	Verify proper jumper settings
	Power supply outputting incorrect voltage	Check power supply
Buss Voltage 1 LED not lit	No voltage on B1 Buss	Check B1 power supply and ABC cable
Buss Voltage 2 LED not lit	No voltage on B2 Buss	Check B2 power supply and ABC cable
Buss Voltage LEDs show different brightness	Normal	This is normal - LED brightness varies with input voltage
FAI LED lit	FAI activated on power supply	Check FAI input on system
FAI LED not lit	FAI not activated on power supply	FAI LED only lights when FAI activated on system
When one power supply indicates fault, the other supply does/doesn't simultaneously indicate fault	Fault Buss Join jumper (JP10) incorrectly set	Set jumper as desired - See Section 5.1.3
When one power supply's FAI activates, the other supply does/doesn't simultaneously activate	FAI Buss Join jumper (JP9) incorrectly set	Set jumper as desired - See Section 5.1.2



## Section 6 Specifications

### 6.1 Electrical Specifications

6.1.1 Input Voltage (B1 and B2)	0-24VDC Nominal; If FAI function is used, one of the voltage busses (B1, or B2) MUST be 12V or higher.
6.1.2 Input Current (B1 and B2)	14A maximum per buss
6.1.3 Battery Requirement	0.01A in addition to output current for each buss. An additional 0.03A will be drawn from the buss with the greater voltage upon an FAI activation.

### 6.2 Temperature Specifications

6.2.1 Ambient Temperature Range	0°C to 49°C (32°F to 120°F)
6.2.2 Ambient Humidity	93% at 32°C (90°F) Maximum

### 6.3 Mechanical Specifications

6.3.1 Weight	0.22 Lbs (Not including hardware or cables)
6.3.2 Size	4.80"L x 2.70"W x 1.15"H NOTE: Width includes terminal block overhang of 0.2"

### 6.3.3 CAD Drawing





Figure 6.3.1

## Appendix A Sample Application

---

### Four Door Access System



### Dual Voltage System with one MB8 and FAI control

- B1 connected to 24V source, B2 connected to 12V source
- MB8 Outputs 1 and 3 set for CB1 to provide constant power for 24V Reader and Keypad
- MB8 Output 2 set for DB1 for 24V to disconnect power from Maglock on Fire Alarm
- MB8 Output 4 set for DB2 for 12V to disconnect power from Maglock on Fire Alarm
- MB8 Output 5 set for EB2 to power 12V doorstrike on Fire Alarm
- MB8 Output 7 set for EB1 to power 24V doorstrike on Fire Alarm
- MB8 Outputs 6 and 8 set for CB2 to provide constant power for 12V Reader and Keypad


## APPENDIX B, PAGE 1

---

### About the Accessory Board Connector

The AlarmSaf Accessory Board Connector (ABC) allows plug-in system expansion using compatible AlarmSaf accessory boards. The ABC is capable of carrying both primary and secondary voltages (if applicable), DC common, fault status, and fire alarm interface status. Products can be daisy-chained together, maintaining voltage, fault, FAI, and DC common continuity throughout the chain.

NOTE: There are 6-pin and 8-pin versions of the ABC. The 6-pin version carries ONLY a single voltage while the 8-pin version can carry two independent voltages for dual voltage systems.



6-Pin and 8-Pin Accessory Board Connectors

\* **NOTE:** The ABC-01 and ABC-02 cables are used only on the older Beacon Power supply boards (PCB#: 38-118 REV A02 or earlier) that have a 6-pin ABC connector. **DO NOT USE** these cables on newer Beacon Power supply boards (PCB # 38-118 REV A03A or later) with 8-pin ABC connector boards or damage to the system could occur.

## APPENDIX B, PAGE 2

---

### About the Accessory Board Connector (continued)

#### Voltage Busses (B1 and B2)

The voltage busses (B1 and B2) are carried on pins 5-8 of the ABC. B1 is the primary voltage, and should typically be the higher of the two voltages in a dual voltage system. The B1 and B2 (if used) voltages are distributed through the accessory boards connected to the ABC. See the documentation for the particular accessory boards being used for details on how to utilize the B1 and/or B2 voltages. Note that 6-pin ABC connectors can carry only the B1 voltage, while 8-pin ABC connectors can carry both B1 and B2. In order for the B2 voltage to be present, a second power supply must be included in the system (AC to DC or DC to DC).

**CAUTION:** If more than one power supply is connected to any of the voltage busses, the system will not operate properly and damage to the system could occur. Verify that only one power supply is connected to each voltage buss before powering the system.

#### Fault Status Buss

The fault status buss carries the DC Fault status between accessory boards and power supplies. Any product with fault detection and/or reporting capability can report a fault to or from the ABC chain. Unless otherwise noted in a product's documentation, AC faults are not transmitted through the fault status buss.

Some accessory boards have a jumper to split the fault buss. This allows the separation of faults between two power supplies in some dual voltage systems. If the buss is not split, any fault on either power supply or any accessory board will show on both power supplies. If the buss is split, faults on each side of the jumper will go to their respective power supply only, allowing easier troubleshooting fault conditions, but requiring monitoring of the fault outputs of both power supplies. Note that only one split should be used in the fault status buss. See the documentation for the accessory boards in the system to determine which, if any, have a fault buss split jumper.

**NOTE:** Not all accessory boards have fault detection or reporting capability, however the fault status is still carried through these accessory boards to maintain continuity through the chain.

## APPENDIX B, PAGE 3

---

### About the Accessory Board Connector (continued)

#### Fire Alarm Interface (FAI) Status Buss

The FAI status buss carries FAI activation signals on systems utilizing a Fire Alarm Interface. This buss is used to control outputs on compatible accessory boards. See the documentation for the accessory boards in the system to determine FAI capability.

Some accessory boards have a jumper to split the FAI buss, allowing independent control of groups of accessory boards and power supplies with multiple FAI input sources. If the buss is not split, all power supplies and accessory boards with FAI capability will change state upon activation of *any* FAI input source in the chain. If the buss is split, FAI activation of any FAI input source will only activate accessory boards or power supplies up to the split. Products after the split require their own FAI input source.

Note: Not all accessory boards have FAI capability; however the FAI status is still carried through these accessory boards to maintain continuity through the chain.

#### DC Common

The DC Common (ground) for the system is maintained through the entire ABC chain. Any power supplies or accessory boards connected to the chain are common grounded through the ABC.

#### Accessory Boards

The following is a list of currently available AlarmSaf Accessory Boards with ABC connectors:

ACCESSORY MODULE		MODULE DESCRIPTION	ABC CABLE	
ORDER	MODEL#		ORDER	MODEL#
10041, 10042	PD8(F)	8 outputs	00521	ABC-03
10067, 10068	MB8(F)	8 outputs w/FAI & voltage selection	00521	ABC-03
10069, 10070	CMB8(F)	8 outputs w/FAI; 4 Relay Controlled	00521	ABC-03
10066	SPS4	Secondary Power Source Module: 5-18V @ 4A	00523	ABC-05
03207	FAIM	Fire Alarm Input Module (used w/PS5-M)	00521	ABC-03
97471	EDB-10	Power Distribution Module for proprietary systems	00523	ABC-05
97472	LDB-8	Power Distribution Module for proprietary systems	00523	ABC-05

## Glossary

---

ABC	See "Accessory Board Connector"
Accessory Board Connector	Connector present on some AlarmSaf power supplies and accessory boards, allowing plug-in expansion of the system
Accessory Board	An AlarmSaf product for use with AlarmSaf power supplies containing an ABC connector. These boards allow plug-in expansion of the functionality of the system. Examples of accessory boards include, but are not limited to, voltage distribution (simple and controlled), secondary DC-DC power supplies, and NAC Circuit expanders.
AC-DC Converter	A DC power supply whose voltage input is either direct from the AC line or through a step-down AC transformer
Buss 1 (B1)	The primary DC voltage in a system. Typically the higher of the two voltages in dual voltage systems
Buss 2 (B2)	The secondary DC voltage in a system. Only dual voltage systems use this voltage.
Class 2 Power Limited	A voltage output or wiring which conforms to NEC Article 725.
Controlled Distribution	Voltage distribution providing on/off control for the outputs. Control can be from FAI, an access control panel, card reader, or other device. The MB8(F) and CMB8(F) accessory boards, and the APD8(F) are examples of controlled distribution.
DC-DC Converter	A DC power supply whose voltage input comes from another DC source. DC-DC converters allow multi-voltage system backup with a single battery set.
FAI	See "Fire Alarm Interface"
Fire Alarm Interface	Input present on some AlarmSaf products allowing control of output(s) in the system. Typically used for dropping power to maglocks on egress doors during a fire alarm condition, but can also be used for other control functions, such as resetting smoke detectors
Negative Trip	An input which is activated upon the switching of a DC Common to its terminals. The DC Common may either be from an external (common grounded) source, or may be provided as one of the terminals of the input, depending on the product. This input type is used with a dry contact or open collector input.
Positive Trip	An input which is activated upon the switching of a positive DC voltage to its terminals. The positive voltage may either be from an external (common grounded) source, or may be provided as one of the terminals of the input, depending on the product. This input type is used with a dry contact or voltage input.
Power Limited	A voltage output or wiring which conforms to NEC Article 725.
PTC	A resettable overcurrent protection device, similar to a fuse or circuit breaker.
Rack Mount	A product which has an enclosure that allows mounting in a standard 19 inch equipment rack
Simple Distribution	Voltage distribution without any control function for the distributed outputs. Power is always available to the outputs. The PD8(F) accessory board is an example of simple distribution.
Voltage Distribution	Splitting a bulk power supply output into multiple, current limited outputs to prevent a single circuit failure from taking down an entire system. The multiple terminal outputs also simplify wiring by providing a pair of terminals for each circuit, rather than wiring several circuits to a single pair of terminals.